


## Reset Operation Guide





When gas is shut off and 【ガス止】indication is displayed in the LCD.











## To reset gas meter

- 1) Shut off all gas appliances.

  Make sure to shut off gas valve
  of boiler located outdoors.

  Do not close main valve of gas meter.
- ②Press reset button.
  (Surrounding area of reset button blinks in red.)

  'A, B and C' indication blinks
  in the LCD instead of 【ガス止】indication.
- 3 Wait for 30 seconds.

  The microprocessor confirms the safety during countdown.
- 4Once ABC indication in the LCD is off, suspension of gas supply is cancelled.

※It may take 90 seconds, depending on the settings.



When 【ガス止】is displayed during 30 seconds<sup>※</sup> countdown, reconfirm whether all gas appliances, including gas appliances using pilot flame, are turned off. Then follow the steps above, again.

•Please contact your gas distributor, if the suspension of gas supply is not cancelled by the above resetting procedure.